

TUNER/GRAPHIC EQUALIZER


C-H5/H51/H5W/H6/H61/H6W/H7

SERVICE MANUAL


(XD-6000/8000/9580 SERIES)

KENWOOD

© 1997-4/B51-5297-00 (K/K) 2341



Metallic cabinet
(A01-3434-01)



PRECAUTIONS FOR REPAIR

C-H5~H7 do not have a power supply transformer. Use A-H5 or PS-94UA power supply to supply power.

Illustration is C-H5.

* Refer to parts list on page 33.

C-H5/H51/H5W/H6/H61/H6W/H7


CONTENTS / ACCESSORIES

Contents

CONTENTS / ACCESSORIES.....	2	SCHEMATIC DIAGRAM.....	15
CONTROLS	3	EXPLODED VIEW	32
CIRCUIT DESCRIPTION	6	PARTS LIST	33
ADJUSTMENT	10	SPECIFICATIONS	Back cover
PC BOARD	11		

Note : On serial test mode, refer to **KR-7080/8080 (B51-5162-00)** Service manual.

Accessories



* Refer to parts list.

System configuration

SYSTEM	TUNER / EQUALIZER	AMPLIFIER	CASSETTE DECK	CD PLAYER	SPEAKER	MD RECORDER
XD-6060	C-H51	A-H5	X-H5	DP-H5	LS-H6	-
XD-6500	C-H5	A-H5	X-H5	DP-MH5	LS-H5	-
XD-6560	C-H51	A-H5	X-H5	DP-MH5	LS-H6	-
XD-8000	C-H6	A-H5	X-H5	DP-H5	LS-H6	-
XD-8550	C-H6	A-H5	X-H5	DP-MH5	LS-H6	-
XD-8560	C-H61	A-H5	X-H5	DP-MH5	LS-H6	-
XD-6000/W	C-H5/W	A-H5	X-H5	DP-H5	LS-H5	-
XD-6050/W	C-H5/W	A-H5	X-H5	DP-H5	LS-H5	-
XD-6550/W	C-H5/W	A-H5	X-H5	DP-MH5	LS-H5	-
XD-8050/W	C-H6/W	A-H5	X-H5	DP-H5	LS-H6	-
XD-8500/W	C-H6	A-H5	X-H5	DP-MH5	LS-H6	-
XD-9580MD	C-H7	A-H5	-	DP-MH5	LS-H6	DM-H5

PCB ASS'Y vs MODEL NAME


PCB NAME	TYPE	MODEL NAME
X04-1313-81	Q	C-H5W/H6W
X05-4650-52	T	C-H5/H6/H7
X05-4652-71	E	C-/H5/H6/H7
X05-4653-82	Q	C-/H5W/H6W
X05-4660-12	K	C-H7
X05-4660-21	Y/M/I	C-H51/H61/H7
X11-3700-21	K/M	C-H7
X11-3700-22	Y/M/I	C-H61
X11-3700-23	Y/M/I	C-H51

PCB NAME	TYPE	MODEL NAME
X11-3700-51	T	C-H7
X11-3700-52	T	C-H6
X11-3700-53	T	C-H5
X11-3702-71	E	C-H7
X11-3702-72	E	C-H6
X11-3702-73	E	C-H5
X11-3703-81	Q	C-H5W
X11-3703-82	Q	C-H6W

C-H5/H51/H5W/H6/H61/H6W/H7

CONTROLS

Tuner/Equalizer Unit (C-H5)



1 EQ. EFFECT Key

The equalizer defect is switched ON/OFF and the type of equalizer effect is selected.

2 EX. BASS (Extra bass) key/Indicator

When power is ON: Press to enhance.

When power is STANDBY: Used in the timer setting operation.

3 DISPLAY/DEMO key

when power is ON: Switches the displayed information. Switches the demonstration on and off.

When power is STANDBY: Switches the demonstration on and off.

4 SRS 3D key/Indicator

When power is ON: Switches the SRS 3D play on and off.

When power is STANDBY: Used in the timer setting operation.

5 MODE key

Press to switch the function of the TUNING UP/DOWN keys. The function which can be selected are variable depending on the condition of the system at each moment.

6 TUNING UP/DOWN key

These keys are usually used to select the broadcast station to be selected. When required, the functions of these keys can be switched with the MODE key.

7 PTY key

8 O.T.T key

Press when setting the O.T.T timer function.

9 RDS DISP. key

10 TA/NEWS/INFO. key

When power is STANDBY: Switches the auto power-save mode on and off.

11 BAND key

Press to switch the receiving band.

12 AUTO key

When power is ON: Switches the tuning mode.

When power is STANDBY: Used in the clock adjustment.

13 ENTER key


Used for time setting, timer setting, etc.

* Please refer to A-H5 service manual on Remote control.

C-H5/H51/H5W/H6/H61/H6W/H7

CONTROLS

Display (C-H5)



1 Tuner and applied operation indicators

This section contains the indicators of the tuner operations as well as applied CD operation.

2 RDS-related indicators

3 Timer-related display

4 Character information display

5 Volume/tone-Timer-related display

This includes the graphic display of the current volume size and the indicators which light up when the equalizer is controlled.


6 Music calendar display

The indicators in this section show the number of tracks recorded on a CD. Each track number indicators turns off when the playback of the track has completed.

7 Graphic equalizer display

The displayed equalizer pattern varies according to the music played. The equalizer pattern display format can be changed as required.

Display (C-H6)



1 Equalizer indicator

This section shows the equalizer pattern in use. The equalizer pattern display format can be switched.

2 MUSIC CALENDAR indicator

3 Volume indicator

The display varies as the **VOLUME CONTROL** of the amplifier unit (A-H5) is operated. Usually, this section shows the current volume setting.

4 Tuner and applied operation indicators

This section contains the indicators of the tuner operations as well as applied CD operation.

5 RDS-related indicators

6 CD-related indicators

These indicators light during recording and playback of CD.

7 Character information indicators

8 Timer reservation program No./MUTE/N.B. indicators

9 Timer-related indicators

10 Equalizer operation indicators

11 Music calendar indicators

The indicators in this section show the number of tracks recorded on a CD. Each track number indicators turns off when the playback of the track has completed.

C-H5/H51/H5W/H6/H61/H6W/H7

CIRCUIT DESCRIPTION

1. INITIAL STATE

AMP SECTION

# POWER ON/STANDBY	: OFF
# SELECTOR	: TUNER
• PROTECTION	: OFF
# MAIN VOLUME	: 7
# L/R BALANCE	: CENTER
• N.B. CIRCUIT	: OFF
# SRS 3D EFFECT LEVEL	: 0
# SRS S3	: OFF
• SOURCE DIRECT	: OFF
• EXTRA BASS	: ON
• MUTE	: OFF
# INPUT LEVEL	: -4dB(DISPLAY -2)
• MD SYSTEM REC LEVEL	: 0dB(NO DISPLAY)

TUNER SECTION

• BAND	: FM
# PRESENT BAND	

1-1. Initializing

The system is initialized when the power is turning on while pressing the <ENTER> key.

2. DESTINATION LIST OF TUNER

Destination	Band	Frequency Range	Channel space	IF	PLL Frequency	Diode SW			
						DSW3	DSW2	DSW1	DSW0
J1 (90.0)	FM	7 6.0MHz ~ 90.0MHz	100kHz	-10.7MHz	25kHz	0	0	1	0
	AM	531kHz ~ 1602kHz	9kHz	+450kHz	9kHz				
K2 (1610)	FM	87.5MHz ~ 108.0MHz	100kHz	+10.7MHz	25kHz	0	0	0	1
	AM	530kHz ~ 1610kHz	10kHz	+450kHz	10kHz				
E1	FM	87.5MHz ~ 108.0MHz	50kHz	+10.7MHz	25kHz	0	0	1	1
	AM	531kHz ~ 1602kHz	9kHz	+450kHz	9kHz				
E3 (RDS)	FM	87.5MHz ~ 108.0MHz	50kHz	+10.7MHz	25kHz	0	1	0	1
	AM	531kHz ~ 1602kHz	9kHz	+450kHz	9kHz				
E4 (LW) (RDS)	FM	87.5MHz ~ 108.0MHz	50kHz	+10.7MHz	25kHz	0	1	1	0
	MW	531kHz ~ 1602kHz	9kHz	+450kHz	9kHz				
	LW	153kHz ~ 279kHz	9kHz	+450kHz	9kHz				
Q (RDS)	FML	65.0MHz ~ 74.0MHz	10kHz	+10.7MHz	5kHz	0	1	1	1
	FMH	87.5MHz ~ 108.0MHz	50kHz	+10.7MHz	5kHz				
	MW	531kHz ~ 1602kHz	9kHz	+450kHz	9kHz				
	LW	153kHz ~ 279kHz	9kHz	+450kHz	9kHz				
M	K2/E1 change only setting "DSW1" (DSW1 = 0 : K2, 1 : E1)					0	0	X	1

※ Diode SW(DSWx) :
 0 = no diode (static mode, LOW)
 1 = diode (static mode, HIGH)
 X = Transistor SW (0=OFF/1=ON)

• FREQUENCY(FM)	: 87.5MHz
• FREQUENCY(AM)	: 531kHz
# PRESENT FREQUENCY	
# AUTO/MONO	: AUTO
• P.CH	: —ch
• TIME	: AM12:00
# PROG. TIMER(1 AND 2)	: WORKING MODE OFF
	: ON=AM12:00
	: OFF=AM12:00
	: MODE=PLAY
	: SOURCE TUNER 01CH
# PROG.EXECUTION	: OFF
• SLEEP TIMER	: OFF
# O.T.T.	: OFF(AM:7:00)

EQUALIZER SECTION

• EQUALIZER	: OFF
# MANUAL CURVE	: FLAT
#	: backup item

C-H5/H51/H5W/H6/H61/H6W/H7

CIRCUIT DESCRIPTION

3. TUNER Preset channel initial data table

Refer to next page.

4. TEST MODE

4-1 Test mode using the unit key

4-1-1 Setting Test Mode

Turn on the power while pressing <TUNING DOWN> key.

4-1-2 Canceling Test Mode

By turning off the power, the system is initialized and the test mode is canceled.

4-2-1 Contents of Test Mode

1) Automatic Power On

- The power on state is entered whenever the power is turned on while pressing the <TUNING DOWN>key. All function are then initialized.
- Sub clock oscillation check function is performed before the test mode. If the check result is OK, the system enters the test mode. The system will stop to work if oscillation NG and period NG with displaying error code5 and 6.

2) Display All Lighting Mode

- In the test mode, all the letters in display are lighted.
- After that, the all lighting mode is canceled when any key is pressed. The normal display obtained. Selector chooses TUNER mode.

3) Special Function

- In the test mode, rec level and input level are set to max.
- In the test mode, remote control is available.

4) Special Function in Tuner Mode

- Mode key: P.CALL DOWN works
- EQ. EFFECT key: P.CALL UP works.

5) Special Function except TUNER Mode

- BAND key: Selects the source direct on/off cyclically every time this key is pressed.
- MODE key: Selects the main volume, balance, eq.manu-al, srs 3D level*, rec level and input level cyclically in the order below every time this key is press.

→ BALANCE → EQ. MANUAL → MAIN VOLUME
 INPUT LEVEL ← REC LEVEL ← SRS LEVEL ←

* SRS 3D off=skip SRS level

- TUNING UP/DOWN key:item selected by MODE key sets to the minimum or maximum an 1 step. However EQ. MANUAL not available.
- AUTO/MONO key: item selected by MODE key is change cyclically in order as follows every time this key is pressed.

BALANCE
 → CENTER → LEFT MAX. → RIGHT MAX. →

EQ.MANUAL
 → FLAT → FULL BOOST → FULL CUT →

MAIN VOLUME
 → MAX.(81) → STEP 1(2) → CENTER(40) →

SRS 3D LEVEL
 → CENTER(0) → MAX.(+10) → MIN.(-10) →
 T4 ← T3 ← T2 ← T1 ←

REC LEVEL
 → MAX.(+2) → MIN.(-2) → CENTER(0) →

INPUT LEVEL
 → MAX.(0) → MIN.(-5) → CENTER(-2) →

- SLEEP/CHRA key:Set rec level after CCRS. If the key is pressed again,normal function is works.
- EX.BASS key: Selects front or rear display cyclically in the order below every time this key is pressed.

→ REAR DISPLAY → FRONT DISPLAY →
 BOTH DISPLAY ←

Etc

- O.T.T. key : Selects the mute on/off cyclically every time this key is pressed.

→ OFF → N.B 1 → N.B 2 →

- ENTER key: Mute on/off

- DISPLAY key: Selects the selector cyclically in the order as follows every time this key is pressed.

→ TUNER → CD → AUX → MD → TAPE →

C-H5/H51/H5W/H6/H61/H6W/H7
CIRCUIT DESCRIPTION


TUNER Preset channel memory

MR	Frequency									
	K1 (1700)		K2 (1610)		E (NO LW)		E (LW)		Q (NO LW)	
1	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
2	FM	97.5MHz	FM	97.5MHz	FM	97.5MHz	FM	97.5MHz	FM	97.5MHz
3	FM	108.0MHz	FM	108.0MHz	FM	108.0MHz	FM	108.0MHz	FM	108.0MHz
4	AM	630kHz	AM	630kHz	AM	630kHz	AM	630kHz	AM	630kHz
5	AM	1000kHz	AM	1000kHz	AM	999kHz	AM	999kHz	AM	999kHz
6	AM	1440kHz	AM	1440kHz	AM	1440kHz	AM	1440kHz	AM	1440kHz
7	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	LW	162kHz	FML	74.0MHz
8	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	LW	216kHz	FML	65.0MHz
9	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	LW	270kHz	FML	69.0MHz
10	FM	89.1MHz	FM	89.1MHz	FM	89.1MHz	FM	89.1MHz	FM	89.1MHz
11	FM	88.0MHz	FM	88.0MHz	FM	88.0MHz	FM	88.0MHz	FM	88.0MHz
12	FM	90.0MHz	FM	90.0MHz	FM	90.0MHz	FM	90.0MHz	FM	90.0MHz
13	FM	98.0MHz	FM	98.0MHz	FM	98.0MHz	FM	98.0MHz	FM	98.0MHz
14	FM	98.5MHz	FM	98.5MHz	FM	98.5MHz	FM	98.5MHz	FM	98.5MHz
15	FM	106.0MHz	FM	106.0MHz	FM	106.0MHz	FM	106.0MHz	FM	106.0MHz
16	AM	530kHz	AM	530kHz	AM	531kHz	AM	531kHz	AM	531kHz
17	AM	990kHz	AM	990kHz	AM	990kHz	AM	990kHz	AM	990kHz
18	AM	1700kHz	AM	1610kHz	AM	1602kHz	AM	1602kHz	AM	1602kHz
19	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	LW	153kHz	FM	87.5MHz
20	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	LW	279kHz	FM	87.5MHz
21	FM	96.3MHz	FM	96.3MHz	FM	96.3MHz	FM	96.3MHz	FM	96.3MHz
22	FM	107MHz	FM	107MHz	FM	107MHz	FM	107MHz	FM	107MHz
23	AM	900kHz	AM	900kHz	AM	900kHz	AM	900kHz	AM	900kHz
24	AM	1350kHz	AM	1350kHz	AM	1350kHz	AM	1350kHz	AM	1350kHz
25	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	LW	225kHz	FM	87.5MHz
26	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
27	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
28	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
29	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
30	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
31	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz
...	...	...	...	...	...	...	...	...	...	...
40	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz	FM	87.5MHz

C-H5/H51/H5W/H6/H61/H6W/H7
CIRCUIT DESCRIPTION

5. Microprocessor : M38198MCA-801FP

5-1. Microprocessor periphery block diagram



C-H5/H51/H5W/H6/H61/H6W/H7

CIRCUIT DESCRIPTION

5-2. Pin description

Pin No.	Pin Name	I/O	Description
1	EX.BASS LED	O	Led control for EXTRA BASS,H=ON
2	SRS 3D LED	O	Led control for SRS 3D, H=ON
3	SPEANA	I	Input port of spectrum analyzer data
4	GE ID CLK	O	Clock control of GE IC(C-H6/7 only)
5	GE ID St	O	Strobe control of GE IC(C-H6/7 only)
6	/PLL DO	I	Input port of IF count
7	/CE	O	Chip enable of PLL IC
8	CLK	O	Clock control of PLL IC
9	DT	O	Data control of PLL IC
10	/STEREO	O	Input port of tuner mode(stereo/mono)
11	/SD	O	Input port of tuner reception
12	S-LEVEL	I	Input port of RDS signal level (A/D input),(T,E,Q type only)
12	ECHO LEVEL	O	Level selector of echo IC, L:level-1,H:level-2(M,I,Y type only)
13	RDS-DATA	I	Input port of RDS data(E,T,Q type only)
13	ECHO /ON-OFF	O	On-off selector of echo IC, L:on, H:OFF(M,I,Y type only)
14	CCRS	I	Input port of CCRS level
15	SELF CHECK	I	Detection port of short test
16	AMP A/D	I	Key input port of amp section(A-H5)
17~20	SEL-1~4	O	Control port of selector IC
21	/PILOT	O	Selector port of PILOT-POLA, L:PILOT(Q type only)
22	/MUTE	O	Control port of mute
23	/P.CON	O	Control port of power
24	E-CLK	O	Clock control port of LED driver IC
25	IC2-SDATA	I/O	Data control port of electronics volume IC
26	IC2-SCLK	O	Clock control port of electronics volume IC
27	SBUSY	I/O	Control port of serial busy signal
28	SDATA	I/O	Control port of serial data signal
29	CCW	I	Input port of rotary encoder counter clockwise signal
30	RDS-SLK	I	Clock input port of RDS IC(E,T,Q type)
31	E-DT	O	Data control of LED driver IC
32	REM	I	Input port of remote control
33	CW	I	Input port of rotary encoder clockwise signal
34	/CE	I	Chip enable
35	/RESET	I	Input port of reset signal
36	XCIN	I	Input port of clock generator for watch
37	XCOUT	O	Output port of clock generator for watch
38	XIN	I	Input port of clock generator for main circuit
39	XOUT	O	Output port of clock generator for main circuit
40	Vss	-	GND
41~44	KR3~0	I	Key return input port
45~54	DIGIT0~9	O	Digit output
55~60	DIGIT10~15	O	No use
61~87	SEGMENT0~26	O	Segment output
88	SEGMENT27	O	Tuner destination selector
89	SEGMENT 28	O	Model selector
90	SEGMENT29	O	Key scan output3
91	Vcc	-	Power supply
92~94	SEGMENT30~32	O	Key scan output2~0
95~97	SEGMENT33~35	O	Selector output port of spean IC
98	Vee	I	-30V power supply
99	Avss	I	Converter gnd of A/D and D/A
100	VREF	I	Standard voltage of A/D and D/A converter

C-H5/H51/H5W/H6/H61/H6W/H7

ADJUSTMENT

FM SECTION INPUT SELECTOR : FM MODE

X05-4650

NO.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
1	DISCRIMINATOR	(A) 98 MHz, 60dBμ (ANT INPUT) 1 kHz, ±40 kHz DEV : E/T/Q TYPE 1 kHz, ±75 kHz DEV (OTHER TYPE)	Connect a DC voltmeter between pin 1 and pin2 of CN2.	MONO 98.0 MHz	L31	0V	(a)
					L32 (EXCEPT K/P)	Minimum distortion.	
2	DISTORTION (STEREO)	(A) 98 MHz, 60dBμ (ANT INPUT) 1 kHz, ±40 kHz DEV : E/T/Q TYPE 1 kHz, ±67.5 kHz DEV PILOT ±7.5 kHz DEV OTHER TYPE	(B)	AUTO 98.0 MHz	T 1 (A1)	Minimum distortion.	(a)

X05-4660


NO.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
1	DISTORTION (STEREO)	(A) 98 MHz, 60dBμ (ANT INPUT) 1 kHz, ±67.5 kHz DEV PILOT: ±7.5 kHz DEV	(B)	AUTO 98.0 MHz	T1 (A1)	Minimum distortion.	

POLAR UNIT

X04-1313-xx Q TYPE (65MHz~74MHz BAND)

NO.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
1	VCO	(C) 69 MHz, 60 dBμ (ANT INPUT) 1 kHz, 0 kHz DEV SUB, 0 kHz DEV	Connect a frequency counter to VCO monitor (CN2).	AUTO 69 MHz	VR 2	Adjust it the frequency counter reads 31.25 kHz ±100 kHz.	
2	SEPARATION	(C) 69 MHz, 60 dBμ (ANT INPUT) 1 kHz, 40 kHz DEV SUB, 10 kHz DEV Select : L or R	Connect a oscilloscope to TUNER OUT(CN6).	AUTO 69 MHz	TC 1	Minimum crosstalk.	
3	SEPARATION	(C) SAME AS ABOVE	Connect a oscilloscope to TUNER OUT(CN6).	AUTO 69 MHz	VR 1	Minimum crosstalk.	


INSTRUMENT CONNECTION



1




○



(X05-466X-XX) M,I,Y,K TYPE

The DC voltage is an actual reading measured with a high impedance type voltmeter as the AM/FM signal generator is specified to the conditions as shown in the list below. The measurement value may vary depending on the measuring instruments used or on the product. The value shown in () is actual reading measured in the AM mode.

MODE	CARRIER	MODULATION		ANT INPUT
		FREQUENCY	DEVIATION	
FM	98MHz	1kHz	STEREO 67.5kHz 7.5kHz(Pilot)	60dB
AM	1000(999)kHz	400Hz	MONO 30% MOD	60dB




K

L

M

N

O



C-H61/H51 (X05-466X-XX)

C-H7/H61/H51(M) (1/4)


DESTINATION	UNIT No.	(A)	C21, 22	W115
COUNTRY	ABB.			
PX	Y			
GENERAL MARKET	M	0-21	YES	0.011
MALAYSIA	I			YES


Y08-5602-70

C-H5/H51/H5W/H6/H61/H6W/H7

KENWOOD


(X05-465X-XX) : T,E,Q TYPE





C-H5/H51/H5W/H6/H61/H6W/H7

KENWOOD



(M,Y,LK) TYPE
X05-CN1

1/4

(T,E) TYPE
X05-CN1

2/4

(Q) TYPE
X04-CN4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

(X11-370X-XX) (A/3)

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC

AD

AE

AF

AG

AH

AI

AJ

AK

1/4

2/4

C

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

AB

AC


AD

AE

AF

AG

AH</



C-H5/H5W/H51/H6/H6W/H61/H7(M) (3/4)

C-H5/H51/H5W/H6/H61/H6W/H7

KENWOOD

Y08-5602-70

C-H7 (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D228	D229	D230	D231	ED1	ED2	S11	S12	S14
EUROPE	E	2-71	YES	NO	NO	YES	YES	NO	NO	NO	NO	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY
U.K.	T	0-51	YES	NO	NO	YES	YES	NO	NO	NO	NO	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY
GENERAL MARKET	M	0-21	NO	NO	YES	YES	YES	YES	NO	YES	YES	NO	NO	YES	YES	NO	NO	MUTE	SLEEP	HITMASTER

C-H8 (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D227	D228	D230	D231	ED1	ED2	S11	S12	S14
EUROPE	E	2-72	YES	NO	NO	YES	YES	NO	NO	NO	NO	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY
U.K.	T	0-52	YES	NO	NO	YES	YES	NO	NO	NO	NO	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY

C-H6W (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D227	D228	D230	D231	ED1	ED2	S11	S12	S14
RUSSIA	Q	3-81	YES	NO	NO	YES	YES	NO	NO	NO	NO	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY

C-H61 (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D227	D228	D230	D231	ED1	ED2	S11	S12	S14
GENERAL MARKET	Y	0-22	NO	YES	NO	YES	YES	YES	YES	NO	NO	YES	YES	NO	YES	NO	NO	ECHO	SLEEP	HITMASTER
MALAYSIA	M	I	0-22	NO	YES	NO	YES	YES	YES	NO	NO	YES	YES	NO	YES	NO	NO	ECHO	SLEEP	HITMASTER

C-H5 (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D227	D228	D230	D231	ED1	ED2	S11	S12	S14
EUROPE	E	2-73	YES	NO	YES	NO	NO	NO	NO	NO	YES	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY
U.K.	T	0-53	YES	NO	YES	NO	NO	NO	NO	NO	YES	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY


C-H5W (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D227	D228	D230	D231	ED1	ED2	S11	S12	S14
RUSSIA	Q	3-82	YES	NO	YES	NO	NO	NO	NO	NO	YES	YES	YES	NO	YES	NO	NO	TA/INFOR	RDS	PTY


C-H51 (11-370X-XX)

DESTINATION	COUNTRY	UNIT No.	WH1	W201	R221	R241-243	Q5-7	Q204	Q209	D225	D226	D227	D228	D230	D231	ED1	ED2	S11	S12	S14
GENERAL MARKET	Y	0-23	NO	YES	YES	YES	NO	NO	YES	YES	NO	NO	NO	YES	ECHO	SLEEP	HITMASTER			
MALAYSIA	M	I	0-23	NO	YES	YES	NO	NO	YES	YES	NO	NO	NO	YES	ECHO	SLEEP	HITMASTER			

ED1



ED2



X11-A/3

-CN3

3/4

D


X11-C/3

-CN6


3/4

E


(X11-370X-XX) (B/3)





ED1 (FRONT GRID)



*ED2







SEL	A	B	C	AOUT
0	X	X	X	GND
1	0	0	0	GND
1	0	0	1	68Hz
1	0	1	0	170Hz
1	1	1	1	420Hz
1	1	0	0	1kHz
1	1	0	1	2.4kHz
1	1	1	0	5.9kHz
1	1	1	1	14.4kHz


 SIGNAL LINE
 GND LINE
 +B LINE
 -B LINE


C-H5/H5W/H51/H6/W6W/H61/H7(M) (4/4)

C-H5/H51/H5W/H6/H61/H6W/H7

KENWOOD

C-H5/H51/H5W/H6/H61/H6W/H7

EXPLODED VIEW



C-H7

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

2

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
641	1A		T90-0820-05	LOOP ANTENNA		
C-H5/H6						
601	1B	*	A01-3427-01	METALLIC CABINET (BLK)	EQT	
601	1B	*	A01-3434-01	BATTERY COVER	EQYMTY	
603	1A	*	A09-0380-08	DRESSING PANEL	EQT	
604	2A	*	A21-1917-02	DRESSING PANEL (SLV)	EQT	5
604	2A	*	A21-1918-02	DRESSING PANEL (BLK)	EQT	5
604	2A	*	A21-1919-02	DRESSING PANEL (SLV)	YMI	5
604	2A	*	A21-1936-12	DRESSING PANEL (BLK)	EQT	6
604	2A	*	A21-1937-12	DRESSING PANEL (SLV)	YMI	6
604	2A	*	A21-1951-12	DRESSING PANEL (SLV)	EQT	6
605	1A	*	A70-1104-05	REMOTE CONTROLLER ASSY5	EQT	
605	1A	*	A70-1104-05	REMOTE CONTROLLER ASSY6	ET	
605	1A	*	A70-1105-05	REMOTE CONTROLLER ASSY5	YMIQ	
605	1A	*	A70-1105-05	REMOTE CONTROLLER ASSY6	YMIQ	
606	2A	*	A60-1009-01	PANEL (SLV)	YMI	
606	2A	*	A60-1010-11	PANEL (SLV)	EQT	
606	2A	*	A60-1111-11	PANEL (BLK)	EQT	
609	2A	*	B07-2333-03	ESCUTCHEON (SLV)	EQYMTI	
609	2A	*	B07-2334-03	ESCUTCHEON (BLK)	EQT	
610	2B	*	B07-2335-04	ESCUTCHEON		
611	2A	*	B10-2280-03	FRONT GLASS		
613	2A	*	B19-1573-04	LENS		
614	2A	*	B43-0301-04	KENWOOD BADGE		
-	-	-	B46-0310-03	WARRANTY CARD	EQT	
-	-	-	B46-0319-00	QUESTIONNAIRE CARD	T	
-	-	-	B46-0328-03	WARRANTY CARD	Y	
-	-	-	B58-0964-13	CAUTION CARD (UL)	Y	
-	-	-	B58-0965-13	CAUTION CARD (PL)	TT	
-	-	-	B58-0966-13	CAUTION CARD (PL)	EM	
-	-	-	B58-1526-03	CAUTION CARD	I	
-	-	-	B59-1104-00	SERVICE DIRECTORY	Q	
-	-	-	B60-2905-00	INSTRUCTION MANUAL (TWN)	Y	
-	-	*	B60-2906-00	INSTRUCTION MANUAL (RUN)	MI	
-	-	*	B60-2907-00	INSTRUCTION MANUAL (PLN)	Q	
-	-	*	B60-3115-00	INSTRUCTION MANUAL (ENG)	Q	
-	-	*	B60-3116-00	INSTRUCTION MANUAL (ENG)	YMI	
-	-	*	B60-3117-00	INSTRUCTION MANUAL (FRE)	T	
-	-	*	B60-3118-00	INSTRUCTION MANUAL (GER)	E	
-	-	*	B60-3119-00	INSTRUCTION MANUAL (NET)	E	
-	-	*	B60-3120-00	INSTRUCTION MANUAL (SPA)	E	
-	-	*	B60-3241-00	INSTRUCTION MANUAL (ITL)	E	
-	-	*	B60-3242-00	INSTRUCTION MANUAL (SPA)	E	
620	1A	*	E03-0115-05	AC PLUG ADAPTER	E	
621	1A	*	E30-2738-05	CORD WITH CONNECTOR	MI	
623	1B	*	E35-1126-05	FLAT CABLE		
-	2B	*	E35-1762-05	FLAT CABLE	YMI	
-	-	-	H10-7246-02	POLYSTYRENE FOAMED FIXTURE		
-	-	-	H10-7247-02	POLYSTYRENE FOAMED FIXTURE		
-	-	-	H13-0086-04	CARTON BOARD		
-	-	-	H25-0632-24	PROTECTION BAG		
-	-	-	H25-0644-04	PROTECTION BAG		
-	-	-	H25-0881-04	PROTECTION BAG		
-	-	-	H50-2149-04	ITEM CARTON CASE		
-	-	-	H50-2150-04	ITEM CARTON CASE		
-	-	-	H50-2438-04	ITEM CARTON CASE		
630	2C	*	J02-0366-15	FOOT		
631	2C	*	J19-3751-04	UNIT HOLDER		
635	2A	*	K29-6490-02	KNOB (3 KEY)		
636	2A	*	K29-6491-04	KNOB (MIC)		
637	2B	*	K29-6603-02	KNOB (7 KEY)		
637	2B	*	K29-6645-02	KNOB (7 KEY)		
638	2A	*	K29-6608-03	KNOB (UP/DOWN)		
640	1A	*	T90-0801-05	LEAD WIRE ANTENNA		
-	1A	*	T90-0802-05	LEAD WIRE ANTENNA		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)

K : USA
T : Europe
X : Australia

P : Canada
E : Europe
M : Other Areas

R : Mexico
G : Germany
Q : Russia

5 : C-H5 series
6 : C-H6 series
7 : C-H7

Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

1

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
C-H7						
601	1B	*	A01-3434-01	METALLIC CABINET		
603	1A	*	A09-0380-08	BATTERY COVER	KM	
604	2A	*	A21-1916-02	DRESSING PANEL	TE	
605	1A	*	A70-1110-05	REMOTE CONTROLLER ASSY	KM	
606	2A	*	A60-1009-01	PANEL	TE	
606	2A	*	A60-1010-11	PANEL	TE	
609	2A	*	B07-2333-03	ESCUTCHEON		
610	2B	*	B07-2335-04	ESCUTCHEON		
611	2A	*	B10-2280-03	FRONT GLASS		
612	1A	*	B19-1529-05	OPTICAL FIBER		
613	2A	*	B19-1573-04	LENS		
614	2A	*	B43-0301-04	KENWOOD BADGE		
-	-	-	B46-0197-00	QUESTIONNAIRE CARD	K	
-	-	-	B46-0310-03	WARRANTY CARD	TE	
-	-	-	B46-0319-00	QUESTIONNAIRE CARD	T	
-	-	-	B46-0328-03	WARRANTY CARD	K	
-	-	-	B58-0964-13	CAUTION CARD (UL)	K	
-	-	-	B58-0965-13	CAUTION CARD (PL)	T	
-	-	-	B58-0966-13	CAUTION CARD (PL)	ME	
-	-	*	B60-2898-00	INSTRUCTION MANUAL(ENG)	KM	
-	-	*	B60-2899-00	INSTRUCTION MANUAL(ENG)	T	
-	-	*	B60-2900-00	INSTRUCTION MANUAL(FRE)	E	
-	-	*	B60-2901-00	INSTRUCTION MANUAL(GER)	E	
-	-	*	B60-2902-00	INSTRUCTION MANUAL(NET)	E	
-	-	*	B60-2903-00	INSTRUCTION MANUAL(ITL)	E	
-	-	*	B60-2904-00	INSTRUCTION MANUAL(SPA)	E	
-	-	*	B60-3114-00	INSTRUCTION MANUAL(TWN)	M	
-	-	*	B60-3121-00	INSTRUCTION MANUAL(SPA)	M	
620	1A	*	E03-0115-05	AC PLUG ADAPTER	M	
621	1A	*	E30-2738-05	CORD WITH CONNECTOR		
623	1B	*	E35-1126-05	FLAT CABLE		
-	2B	*	E35-1762-05	FLAT CABLE	KM	
-	-	-	H10-7246-02	POLYSTYRENE FOAMED FIXTURE		
-	-	*	H10-7247-02	POLYSTYRENE FOAMED FIXTURE		
-	-	*	H13-0086-04	CARTON BOARD		
-	-	*	H25-0632-24	PROTECTION BAG	KME	
-	-	*	H25-0644-04	PROTECTION BAG	T	
-	-	-	H25-0881-04	PROTECTION BAG		
-	-	-	H50-2149-04	ITEM CARTON CASE	TE	
-	-	-	H50-2150-04	ITEM CARTON CASE	M	
-	-	-	H50-2438-04	ITEM CARTON CASE	K	
630	2C	*	J02-0366-15	FOOT		
631	2C	*	J19-3751-04	UNIT HOLDER		
635	2A	*	K29-6490-02	KNOB (3 KEY)		
636	2A	*	K29-6491-04	KNOB (MIC)	KM	
637	2B	*	K29-6603-02	KNOB (7 KEY)	TE	
637	2B	*	K29-6645-02	KNOB (7 KEY)	TE	
638	2A	*	K29-6608-03	KNOB (UP/DOWN)	TE	
640	1A	*	T90-0801-05	LEAD WIRE ANTENNA	KM	
-	1A	*	T90-0802-05	LEAD WIRE ANTENNA	TE	

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)

K : USA
T : Europe
X : Australia

P : Canada
E : Europe
M : Other Areas

R : Mexico
G : Germany
Q : Russia

5 : C-H5 series
6 : C-H6 series
7 : C-H7

Δ indicates safety critical components.

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
L2 ,3			L79-1236-05	LC FILTER		
L4			L40-1021-14	SMALL FIXED INDUCTOR(1.0MH,K)		
R9			RS14KB3A221J	FL-PROOF RS 220 J 1W		
VR1			R12-3685-05	TRIMMING POT (10K)		
VR2			R12-1619-05	TRIMMING POT.(4.7K)		
D1			MTZJ5.1(B)	ZENER DIODE		
D1 ,3			UZ-5.1BSB	ZENER DIODE		
D2 ,3			HSS104	DIODE		
D2 ,3			1SS133	DIODE		
D4			MTZJ5.1(B)	ZENER DIODE		
D4 ,7			UZ-5.1BSB	ZENER DIODE		
D6 ,7			HSS104	DIODE		
D6 ,7			1SS133	DIODE		
IC1			IR3842	ANALOGUE IC		
IC2			NJM4565D	ANALOGUE IC		
IC3			TC4052BP	IC(4CH MPX/DE-MPX)		
Q1			2SA1175(F,E)	TRANSISTOR		
Q1			2SA933AS(Q,R)	TRANSISTOR		
O5			DTC124ESA	DIGITAL TRANSISTOR		
O5			UN4212	DIGITAL TRANSISTOR		
TUNER (X05-4652-71) TEQ type						
C1			CE04LW1C470M	ELECTRO		
C2			CE04LW1H010M	ELECTRO		
C2 ,8			CK73FB1H103K	CHIP C		
C3			C91-0769-05	CERAMIC		
C30			CK73EB1E473K	CHIP C		
C31			CE04LW1C470M	ELECTRO		
C32			CK73FB1H103K	CHIP C		
C33			CE04LW1C100M	ELECTRO		
C34			CK73EB1E104K	CHIP C		
C35			CE04LW1C100M	ELECTRO		
C36			CK73FB1E473K	CHIP C		
C37			CK73EF1E105Z	CHIP C		
C38			C90-3217-05	ELECTRO		
C39			CK73FL1H101J	CHIP C		
C40			C90-3253-05	ELECTRO		
C41			C90-3251-05	ELECTRO		
C42			C90-3240-05	ELECTRO		
C43			CE04LW1HR47M	ELECTRO		
C44			CK73FB1E473K	CHIP C		
C45			CK73FC1H1220J	CHIP C		
C46			CE04LW1A101M	ELECTRO		
C47			CK73FB1H682K	CHIP C		
C48			CK73FSL1H101J	CHIP C		
C49			C90-3253-05	ELECTRO		
C50			CK73FB1H102K	CHIP C		
C51 ,52			C90-3217-05	ELECTRO		
C53 ,54			CK73FB1H223K	CHIP C		
C55 ,56			C90-3231-05	ELECTRO		
C55 ,56			C90-3240-05	ELECTRO		
C57 ,58			CK73FB1H682K	CHIP C		
C59			CK73ESL1H101J	CHIP C		
C60			CK73FB1E104K	CHIP C		
C61			CK73FB1H103K	CHIP C		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
-			H25-0691-04	PROTECTION BAG		
-			H50-2152-04	ITEM CARTON CASE (SLV)	5	ET
-			H50-2153-04	ITEM CARTON CASE (SLV)	5	MI
-			H50-2255-04	ITEM CARTON CASE (SLV)	6	ET
-			H50-2256-04	ITEM CARTON CASE (SLV)	6	MI
-			H50-2257-04	ITEM CARTON CASE (SLV)	6	Y
-			H50-2313-04	ITEM CARTON CASE (SLV)	5	Y
-			H50-2315-04	ITEM CARTON CASE (SLV)	5	Y
-			H50-2317-04	ITEM CARTON CASE (SLV)	6	Q
-			H50-2348-04	ITEM CARTON CASE (BLK)	5	ET
-			H50-2349-04	ITEM CARTON CASE (BLK)	5	Q
-			H50-2350-04	ITEM CARTON CASE (BLK)	6	ET
-			H50-2412-04	ITEM CARTON CASE (BLK)	6	Q
630	2C		J02-0366-15	FOOT		
631	2C		J19-3751-04	UNIT HOLDER		
635	2A		K29-6490-02	KNOB (3 KEY) (SLV)	6	EQYMTI
635	2A		K29-6607-02	KNOB (3 KEY) (BLK)	6	EQYMTI
635	2A		K29-6646-02	KNOB (3 KEY) (SLV)	5	EQYMTI
635	2A		K29-6647-02	KNOB (3 KEY) (BLK)	5	EQYMTI
636	2A		K29-6649-04	KNOB (MIC) (SLV)	5	YMI
637	2B		K29-6603-02	KNOB (7 KEY) (SLV)		YMI
637	2B		K29-6623-02	KNOB (7 KEY) (BLK)		EQY
637	2B		K29-6645-02	KNOB (7 KEY) (SLV)		EQY
638	2A		K29-6608-03	KNOB (UP/DOWN) (SLV)		EQYMTI
638	2A		K29-6609-03	KNOB (UP/DOWN) (BLK)		EQY
640	1A		T90-0801-05	LEAD WIRE ANTENNA		YMI
640	1A		T90-0809-05	LEAD WIRE ANTENNA		EQY
641	1A		T90-0820-05	LOOP ANTENNA		
MPX (X04-1313-82) Q type only						
C1			CE04LW1H010M	ELECTRO		
C2 ,3			C91-1566-05	PF-C	1.0UF	50WV
C4			CE04LW1A470M	ELECTRO	0.01UF	G
C5 ,6			CQ93FMG1H102J	MYLAR	47UF	10WV
C7			CC45FSLH331J	CERAMIC	1000PF	J
C8			CK45FB1H102K	CERAMIC	330PF	J
C9			CC93FCH1H471J	CERAMIC	1000PF	K
C10 ,11			CE04LW1HR47M	CERAMIC	470PF	J
C12			CK45FF1H473Z	ELECTRO	0.47UF	50WV
C13 -15			CE04LW1H010M	ELECTRO	0.047UF	Z
C16			CK45FF1H103Z	ELECTRO	1.0UF	50WV
C17 ,18			CE04LW1H2R2M	CERAMIC	0.010UF	Z
C19 ,20			CQ93FMG1H682J	MYLAR	2.2UF	50WV
C21			CK45FF1H103Z	ELECTRO	6800PF	J
C22			CE04LW1A470M	ELECTRO	0.010UF	Z
C23 ,24			CQ93FMG1H472J	MYLAR	47UF	10WV
C25			CC45FSLH121J	CERAMIC	4700PF	J
C26			CE04LW1H2R2M	ELECTRO	120PF	J
TC1			C05-0463-05	CERAMIC TRIMMER CAPACITOR(120P	2.2UF	50WV
CN2 ,3			E40-4871-05	PIN ASSY		
CN4			E40-4372-05	PIN ASSY		
CN5			E40-3259-05	PIN ASSY		
CN6			E40-4872-05	PIN ASSY		
L1			L39-1350-05	PEAKING COIL		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

6

Ref. No	Add. res	New Parts	Parts No.	Description	Desti- nation	Re- marks
R10			RK73FB2A332J	CHIP R	1/10W	
R11			RK73FB2A681J	CHIP R	1/10W	
R12			RK73FB2A122J	CHIP R	1/10W	
R13 ,14			RK73FB2A331J	CHIP R	1/10W	
R15			RK73FB2A101J	CHIP R	1/10W	
R16			RK73FB2A330J	CHIP R	1/10W	ET
R17			RK73FB2A470J	CHIP R	1/10W	Q
R18			RK73FB2A621J	CHIP R	1/10W	
R19			RK73FB2A4R7J	CHIP R	1/10W	
R20			RK73FB2A122J	CHIP R	1/10W	
R31			RS14KB3A820J	FL-PROOF RS	1W	
R32			RK73EB2B562J	CHIP R	1/8W	
R33			RK73FB2A302J	CHIP R	1/10W	
R34			RK73FB2A822J	CHIP R	1/10W	
R35			RK73FB2A333J	CHIP R	1/10W	
R36			RK73FB2A393J	CHIP R	1/10W	
R37			RK73FB2A272J	CHIP R	1/10W	
R38			RK73FB2A333J	CHIP R	1/10W	
R39			RK73FB2A223J	CHIP R	1/10W	
R40			RK73FB2A332J	CHIP R	1/10W	
R41			RK73FB2A222J	CHIP R	1/10W	
R42			RK73FB2A473J	CHIP R	1/10W	
R43 ,44			RK73FB2A242J	CHIP R	1/10W	Q
R43 ,44			RK73FB2A332J	CHIP R	1/10W	ET
R45			RK73FB2A102J	CHIP R	1/10W	ET
R46			RK73FB2A122J	CHIP R	1/10W	
R47 ,48			RK73FB2A392J	CHIP R	1/10W	
R49			RK73FB2A473J	CHIP R	1/10W	
R51			RK73FB2A102J	CHIP R	1/10W	
R52			RK73FB2A104J	CHIP R	1/10W	
R53			RK73FB2A102J	CHIP R	1/10W	
R54			RK73FB2A683J	CHIP R	1/10W	
R55			RK73FB2A473J	CHIP R	1/10W	
R56			RK73FB2A104J	CHIP R	1/10W	
R59			RK73FB2A222J	CHIP R	1/10W	QT
R61			RK73FB2A223J	CHIP R	1/10W	QT
R62			RK73FB2A105J	CHIP R	1/10W	QT
R63			RK73FB2A473J	CHIP R	1/10W	QT
R64			RK73FB2A103J	CHIP R	1/10W	QT
R65			RK73FB2A153J	CHIP R	1/10W	QT
R66			RK73FB2A152J	CHIP R	1/10W	QT
R67			RK73FB2A104J	CHIP R	1/10W	QT
R68			RK73FB2A222J	CHIP R	1/10W	QT
R70			RK73FB2A105J	CHIP R	1/10W	QT
R80			RK73EB2B102J	CHIP R	1/8W	
R81 -83			RK73FB2A102J	CHIP R	1/10W	
R84			RK73FB2A103J	CHIP R	1/10W	
R85 -88			RK73FB2A102J	CHIP R	1/10W	
R89			RD14NB2E101J	RD	1/4W	
R90			RK73FB2A562J	CHIP R	1/10W	
R91			RK73FB2A222J	CHIP R	1/10W	
R92			RK73FB2A123J	CHIP R	1/10W	
R93			RK73FB2A122J	CHIP R	1/10W	
R94			RD14NB2E561J	RD	1/4W	

△

△

△

L : Scandinavia
Y : PFI(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
△ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

5

Ref. No	Add. res	New Parts	Parts No.	Description	Desti- nation	Re- marks
C62			CK73FB1H333K	CHIP C	0.033UF	QT
C63			CK73FCH1H090D	CHIP C	9.0PF	QT
C64			CK73FB1H333K	CHIP C	0.033UF	D
C66			CK73FCH1H060D	CHIP C	6.0PF	D
C67			CK73FCH1H220J	CHIP C	22PF	J
C67			CK73FCH1H330J	CHIP C	33PF	J
C68			CK73FSL1H020C	CHIP C	20PF	E
C69			CK73FB1H103K	CHIP C	0.010UF	Q
C70			CK73FSL1H101J	CHIP C	100PF	
C79			CK73FSL1H101J	CHIP C	100PF	
C80			CK73FSL1H101J	CHIP C	100PF	
C81			CK73FCH1H220J	CHIP C	22PF	J
C82			CK73FCH1H270J	CHIP C	27PF	J
C83 ,84			CK73FB1H102K	CHIP C	1000PF	K
C85			C91-0745-05	CERAMIC	100PF	K
C86			C91-0757-05	CERAMIC	1000PF	K
C87			CE04LW1A470M	ELECTRO	47UF	10WV
C88			CK73FSL1H331J	CHIP C	330PF	J
C89			CE04LW1C470M	ELECTRO	18WV	
C90			CE04LW1H2R2M	ELECTRO	2.2UF	50WV
C91			CQ93FMG1H223J	MYLAR	0.022UF	J
C92			CK73FSL1H471J	CHIP C	470PF	J
C93			CK73FB1H103K	CHIP C	0.010UF	K
C94			CK73FB1H102K	CHIP C	1000PF	K
C95			CK73FCH1H470J	CHIP C	47PF	J
C96			CK73FSL1H101J	CHIP C	100PF	J
CN1			E40-9831-05	SOCKET FOR PIN ASSY		
CN2			E40-4871-05	PIN ASSY		
J1			E20-0321-05	LOCK TERMINAL BOARD(2P.F)		
J1			E70-0052-05	LOCK TERMINAL BOARD		
J2			F10-1053-04	SHIELDING PLATE		
J2			F10-1088-04	SHIELDING PLATE		
CF1 ,2			L72-0536-05	CERAMIC FILTER		
L31			L30-0929-05	FM IFT		
L32			L30-0930-05	FM IFT		
L33			L30-0911-05	AM IFT		
L34			L79-1237-05	LC FILTER		
L35 ,36			L79-1236-05	LC FILTER		
L61			L40-1091-17	SMALL FIXED INDUCTOR(1UH)		
L62			L39-1351-05	COMBINATION COIL		
L62			L39-1352-05	COMBINATION COIL		
L63			L40-1001-17	SMALL FIXED INDUCTOR(10UH,K)		
L81			L40-1091-17	SMALL FIXED INDUCTOR(1UH)		
X31			L78-0837-05	RESONATOR	(456KHZ)	
X81			L77-1122-05	CRYSTAL RESONATOR(7.2MHZ)		
R1			RD14NB2E101J	RD	100	J 1/4W
R2			RK73EB2B221J	CHIP R	220	J 1/8W
R3			RK73FB2A332J	CHIP R	3.3K	J 1/10W
R4			RK73FB2A681J	CHIP R	680	J 1/10W
R5			RK73FB2A331J	CHIP R	330	J 1/10W
R6			RK73FB2A220J	CHIP R	22	J 1/10W
R7			RK73FB2A332J	CHIP R	3.3K	J 1/10W
R8			RK73FB2A331J	CHIP R	330	J 1/10W

△

L : Scandinavia
Y : PFI(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
△ indicates safety critical components.

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
C9			CE04LW1C100M	ELECTRO		
C10			CK73FB1H473K	CHIP C	16WV	
C11			CE04LW1H010M	ELECTRO	0.047UF	
C12			CE04LW1H2R2M	ELECTRO	1.0UF	
C13			CK73FB1H102K	CHIP C	2.2UF	
C14			CE04LW1H010M	ELECTRO	1000PF	
C15			CE04LW1H010M	CHIP C	1.0UF	
C16			CE04LW1C100M	CHIP C	22PF	
C17			CK73FB1H562K	ELECTRO	10UF	
C18			CK73FB1H102K	CHIP C	5600PF	
C19			CE04HW1E4R7M	NP-ELEC	1000PF	
C20			CK73FB1E104K	CHIP C	4.7UF	
C21 ,22			CO93FMG1H113J	MYLAR	0.10UF	YMI
C21 ,22			CO93FMG1H163J	MYLAR	0.011UF	K
C23			CE04LW1H010M	ELECTRO	0.018UF	
C25			CE04LW1C100M	ELECTRO	1.0UF	
C26			CE04LW1C470M	ELECTRO	10UF	
C27			CE04LW1H010M	ELECTRO	47UF	
C28			CO93FMG1H223J	MYLAR	1.0UF	
C29			CE04LW1H2R2M	ELECTRO	0.022UF	
C30			CE04LW1C101M	ELECTRO	2.2UF	
C31			CE04LW1A470M	ELECTRO	100UF	
C32			CK73FB1H103K	CHIP C	16WV	
C33			CK73FSL1H101J	CHIP C	47UF	
C34 ,35			CK73FB1H102K	CHIP C	0.010UF	
C36			CC73FCH1H270J	CHIP C	100PF	
C37			CC73FCH1H220J	CHIP C	1000PF	
C38			CK73FB1H471K	CHIP C	27PF	
C52			CC73FCH1H470J	CHIP C	22PF	
C57 -60			CE04LW1H010M	ELECTRO	470PF	
C61 ,62			CO93FMG1H472J	MYLAR	1.0UF	
C63			CC73FCH1H220J	CHIP C	4700PF	
C64			CK73FB1H473K	CHIP C	22PF	
CN1			E40-9831-05	SOCKET FOR PIN ASSY		
J1			E20-0476-05	LOCK TERMINAL BOARD(4P)		
J1			E70-0051-05	LOCK TERMINAL BOARD		
J2			F10-0945-04	SHIELDING PLATE		
CF1 ,2			L72-0531-05	CERAMIC FILTER		
L1			L72-0593-05	CERAMIC FILTER		
L2			L39-1348-05	COMBINATION COIL		
L3 ,4			L30-0911-05	AM/IFT		
X1			L40-1091-17	SMALL FIXED INDUCTOR(1UH)		
X2			L77-1122-05	CRYSTAL RESONATOR(7.2MHZ)		
R1			L78-0637-05	RESONATOR (456KHZ)		
R2			RK73FB2A332J	CHIP R	3.3K	
R3			RK73FB2A681J	CHIP R	680	
R4 ,5			RK73FB2A100J	CHIP R	10	
R6			RK73FB2A331J	CHIP R	330	
R7			RK73FB2A101J	CHIP R	100	
R8			RK73FB2A473J	CHIP R	47K	
R13			RK73FB2A331J	CHIP R	330	
R15 ,16			RK73FB2A333J	CHIP R	33K	
			RK73FB2A393J	CHIP R	39K	

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
P : Canada
E : Europe
T : Europe
X : Australia
R : Mexico
G : Germany
M : Other Areas
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add- ress	New Parts	Parts No.	Description	Desti- nation	Re- marks
W51 -55			R92-0670-05	CHIP R	E	
W53			R92-0670-05	CHIP R	QT	
W56 -58			R92-0670-05	CHIP R	ET	
W59			R92-0670-05	CHIP R	Q	
W61			R92-0670-05	CHIP R	ET	
W62 -67			R92-0670-05	CHIP R	Q	
W68			R92-0670-05	CHIP R	QT	
W69 -71			R92-0670-05	CHIP R	Q	
W69 -72			R92-0670-05	CHIP R	ET	
W73			R92-0670-05	CHIP R	Q	
W74			R92-0670-05	CHIP R	ET	
W75			R92-0670-05	CHIP R	Q	
W75 ,76			R92-0670-05	CHIP R	ET	
W79 ,80			R92-0670-05	CHIP R	Q	
W80			R92-0670-05	CHIP R	ET	
W82			R92-0670-05	CHIP R	Q	
W83 -85			R92-0670-05	CHIP R	ET	
W83 ,84			R92-0670-05	CHIP R	Q	
D1			HSS104	DIODE		
D1			1SS133	DIODE		
D31			MTJ8.2(B)	ZENER DIODE		
D31			UZ-8.2BSB	ZENER DIODE		
D32			MA111	DIODE		
D33			HSS104	DIODE		
D33			1SS133	DIODE		
D61 ,62			HSS104	DIODE		
D61 ,62			1SS133	DIODE		
D81			MTJ36.1(B)	ZENER DIODE		
D81			UZ-5.1BSB	ZENER DIODE		
IC1			LA1836	ANALOGUE IC		
IC2			LC72131	MOS-IC		
IC3			NJM2904M	IC(OP AMP X2)		
Q1 ,2			2SC2714(R,O)	TRANSISTOR		
Q3			2SA1576A(R,S)	TRANSISTOR		
Q3			2SB1218A(Q,R)	TRANSISTOR		
Q31 ,32			2SC4081(R,S)	TRANSISTOR		
Q31 ,32			2SD1819A(Q,R)	TRANSISTOR		
Q61 ,62			2SC4081(R,S)	TRANSISTOR		
Q61 ,62			2SD1819A(Q,R)	TRANSISTOR		
Q63			2SC2878(B)	TRANSISTOR		
Q64			2SA1576A(R,S)	TRANSISTOR		
Q64			2SB1218A(Q,R)	TRANSISTOR		
Q65			2SK302(Y,GR)	FET		
Q81			2SA1576A(R,S)	TRANSISTOR		
Q81			2SB1218A(Q,R)	TRANSISTOR		
A1			W02-2565-05	FM FRONT-END ASSY		
A1			W02-2579-05	FM FRONT-END ASSY		
TUNER (X05-4660-12) KYMI type						
C1 ,2			CK73FB1H103K	CHIP C		
C3			CC73FCH1H040C	CHIP C	0.010UF	
C5			CK73FB1H222K	CHIP C	4.0PF	
C7			CK73FB1H102K	CHIP C	2200PF	
C8			CK73FB1H103K	CHIP C	1000PF	
				CHIP C	0.010UF	

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
P : Canada
E : Europe
T : Europe
X : Australia
R : Mexico
G : Germany
M : Other Areas
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
CONTROL (X11-3700-00)						
D232,233			B30-2494-05	LED(GRN)		
C1			CE04KW1H100M	ELECTRO		
C2			CE04KW1E222M	ELECTRO	10UF	50WV
C3			CE04KW1H100M	ELECTRO	2200UF	25WV
C4			C90-3264-05	ELECTRO	10UF	50WV
C5			CK45FF1H103ZMU	CERAMIC	470UF	6.3WV
C6			CK45FB1H152KMU	CERAMIC	0.010UF	Z
C7			C90-3730-05	ELECTRO	1500PF	K
C8			CE04KW1E222M	ELECTRO	120UF	35WV
C9			CE04KW1E102M	ELECTRO	2200UF	25WV
C10			CE04KW1H100M	ELECTRO	1000UF	25WV
C11	67		CE04KW1H100M	ELECTRO	10UF	50WV
C12,13			CE04KW1H100M	ELECTRO	10UF	50WV
C14			CQ93FMG1H103J	MYLAR	0.010UF	J
C15			CE04KW1H100M	ELECTRO	10UF	50WV
C16			CF92EV1H124J	MF-C	0.12UF	J
C17			CE04KW1C101M	ELECTRO	100UF	16WV
C18-20			CE04KW1H100M	ELECTRO	10UF	50WV
C21-26			CE04KW1V477M	ELECTRO	4.7UF	35WV
C27,28			CE04KW1V220M	ELECTRO	22UF	35WV
C29			CE04KW1C221M	ELECTRO	220UF	16WV
C30-32			CC45FSL1H101JM	CERAMIC	100PF	J
C33-36			CE04KW1V477M	ELECTRO	4.7UF	35WV
C37-40			CE04KW1H0R1M	ELECTRO	0.1UF	50WV
C41,42	5		CQ93FMG1H223J	MYLAR	0.022UF	J
C43,44	5		CQ93FMG1H183J	MYLAR	0.018UF	J
C45			CE04KW1H477M	ELECTRO	4.7UF	50WV
C46			CE04KW1V477M	ELECTRO	470UF	35WV
C48			CE04KW1H0R1M	ELECTRO	0.1UF	50WV
C51			CQ93FMG1H472J	MYLAR	4700PF	J
C52,53			CF92EV1H474J	MF-C	0.47UF	J
C54,55	5		CQ93FMG1H562J	MYLAR	5600PF	J
C56,57			CC45FSL1H101JM	CERAMIC	100PF	J
C58	56		CE04KW1H100M	ELECTRO	10UF	50WV
C59			CE04KW1H100M	ELECTRO	10UF	50WV
C60	56		CE04KW1H100M	ELECTRO	10UF	50WV
C61			CE04KW1V470M	ELECTRO	47UF	35WV
C62			CE04KW1H010M	ELECTRO	1.0UF	50WV
C63-66			CE04KW1H100M	ELECTRO	10UF	50WV
C67,68			CE04KW1V220M	ELECTRO	22UF	35WV
C69,70			CQ93FMG1H103J	MYLAR	0.010UF	J
C71,72			CE04KW1C470M	ELECTRO	47UF	16WV
C73			CE04KW1H100M	ELECTRO	10UF	50WV
C74			CE04KW1H100M	ELECTRO	10UF	50WV
C75			CE04KW1H2R2M	NP-ELEC	2.2UF	50WV
C76			C90-3307-05	ELECTRO	470UF	35WV
C77			C90-3265-05	ELECTRO	1000UF	6.3WV
C78,80			CC45FSL1H221JM	CERAMIC	220PF	J
C83,84			CC45FSL1H221JM	CERAMIC	220PF	J
C87-94			CC45FSL1H221JM	CERAMIC	220PF	J
C97,98			CC45FSL1H221JM	CERAMIC	220PF	J
C103,104			CC45FSL1H221JM	CERAMIC	220PF	J

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R17			RK73FB2A271J	CHIP R	1/10W	
R18			RK73FB2A302J	CHIP R	J	
R19			RK73FB2A822J	CHIP R	J	
R21-23			RK73FB2A102J	CHIP R	J	
R24			RK73FB2A562J	CHIP R	J	
R25			RD14NB2E101J	RD	J	
R26			RD14NB2E561J	RD	J	
R27			RK73FB2A102J	CHIP R	J	
R28			RK73FB2A103J	CHIP R	J	
R29,30			RK73FB2A102J	CHIP R	J	
R31			RK73FB2A103J	CHIP R	J	
R32			RK73FB2A123J	CHIP R	J	
R33			RK73FB2A123J	CHIP R	J	
R41			RS14KB3A181J	FL-PROOF RS	J	
R42			RD14NB2E820J	RD	J	
R43			RD14NB2E221J	RD	J	
R44			RK73FB2A101J	CHIP R	J	
R46			RK73FB2A104J	CHIP R	J	
R47			RK73FB2A153J	CHIP R	J	
R48			RK73FB2A473J	CHIP R	J	
R49			RK73FB2A473J	CHIP R	J	
R50			RK73FB2A471J	CHIP R	J	
R51-54			RK73FB2A473J	CHIP R	J	
R55,56			RK73FB2A154J	CHIP R	J	
R59,60			RK73FB2A332J	CHIP R	J	
W101-106			R92-0670-05	CHIP R	J	
W108-114			R92-0670-05	CHIP R	J	
W115			R92-0670-05	CHIP R	J	
W117,118			R92-0670-05	CHIP R	J	
W119			R92-0670-05	CHIP R	J	
W203-208			R92-0679-05	CHIP R	J	
W210,211			R92-0679-05	CHIP R	J	
S1			S62-0034-05	SLIDE SWITCH		
D1,2			HSS104	DIODE		
D1,2			1S5133	DIODE		
D3,4			MTZJ5.1(B)	ZENER DIODE		
D3,4			UZ5.1BSB	ZENER DIODE		
D8			HSS104	DIODE		
D8			1S5133	DIODE		
D10			MA111	DIODE		
IC1			LA1832	ANALOGUE IC		
IC2			LC72131	MOS-IC		
IC4			NJM4565M	IC(OP AMP X2)		
Q1			2SC2714(R,O)	TRANSISTOR		
Q3			2SA1576(R,S)	TRANSISTOR		
Q3			2SB1218(Q,R)	TRANSISTOR		
Q5			2SC4081(R,S)	TRANSISTOR		
Q5			2SD1819A(Q,R)	TRANSISTOR		
Q9,10			2SC4081(R,S)	TRANSISTOR		
Q9,10			2SD1819A(Q,R)	TRANSISTOR		
A1			W02-2539-05	FM FRONT-END ASSY		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
C105, 106			CK45FB1H102KMU	CERAMIC		
C107			CC45FSL1H221JM	CERAMIC		
C108			CF92FV1H124J	MYLAR		
C109-112			CC45FSL1H101JM	CERAMIC		
C113			CK45FB1H102KMU	CERAMIC		
C114			CE04KW1H4R7M	ELECTRO		
C115, 116	67		CF92FV1H224J	MYLAR		
C117, 118	67		CF92FV1H184J	MYLAR		
C119-122	67		CF92FV1H104J	MYLAR		
C123-126	67		CF92FV1H333J	MYLAR		
C127, 128			CC45FSL1H123J	CERAMIC		
C129, 130	67		CC45FSL1H153J	CERAMIC		
C131-134	67		CC45FSL1H682J	CERAMIC		
C135-138	67		CK45FB1H222KMU	CERAMIC		
C139-142	67		CK45FB1H821KMU	CERAMIC		
C143, 144	67		CE04KW1H4R7M	ELECTRO		
C145, 146	67		CE04KW1H100M	ELECTRO		
C149	67		CE04KW1H100M	ELECTRO		
C151, 152			CC45FSL1H221JM	CERAMIC		
C153, 154			CK45FB1H471KMU	CERAMIC		
C155-158			CC45FSL1H101JM	CERAMIC		
C201			CK45FF1H103ZMU	CERAMIC		
C202			CE04KW1H010M	ELECTRO		
C204			CE04KW0J331M	ELECTRO		
C205			CE04KW1A101M	ELECTRO		
C209, 210			CC45FSL1H180J	CERAMIC		
C211			CC45FF1H103ZMU	CERAMIC		
C212			CE04KW1H010M	ELECTRO		
C213			C90-3214-05	ELECTRO		
C214			CE04KW1A101M	ELECTRO		
C215			CE04KW1H010M	ELECTRO		
C216			CE04KW1H010M	ELECTRO		
C217			C90-3225-05	ELECTRO		
C218			CK45FB1H561KMU	CERAMIC		
C219			CE04KW1A101M	ELECTRO		
C221, 222			CC45FSL1H103ZMU	CERAMIC		
C223, 224			CC45FSL1H470J	CERAMIC		
C225, 226			CE04KW1H010M	ELECTRO		
C232			CK45FB1H561KMU	CERAMIC		
C234			CF92FV1H124J	MYLAR		
C235			CC45FSL1H331JM	CERAMIC		
C236			CE04KW1H472J	MYLAR		
C237			CC45FSL1H103ZMU	CERAMIC		
C320			CC45FSL1H331JM	CERAMIC		
C401			CC45FSL1H103ZMU	CERAMIC		
C402			CC45FSL1H153J	CERAMIC		
C403			CC45FSL1H103ZMU	CERAMIC		
C405			CC45FSL1H103ZMU	CERAMIC		
C406			CC45FSL1H103ZMU	CERAMIC		
C407			CE04KW1H010M	ELECTRO		
C408			CC45FSL1H101JM	CERAMIC		
C409, 410			CE04KW1C470M	ELECTRO		
C411	56		CE04KW1H010M	ELECTRO		
C412	56		CE04KW1H100M	ELECTRO		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
P : Canada
T : Europe
X : Australia
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
C413			CE04KW1A101M	ELECTRO		
C414, 415	56		CE04KW1V220M	ELECTRO		
C416	56		CQ93FMG1H103J	MYLAR		
C417	56		CF92FV1H474J	MYLAR		
C418	56		CQ93FMG1H103J	MYLAR		
C419	56		CK45FB1H332K	CERAMIC		
C420	56		CQ93FMG1H472J	MYLAR		
C421	56		CQ93FMG1H103J	MYLAR		
C422	56		CQ93FMG1H123J	MYLAR		
C423	56		CE04KW1H010M	ELECTRO		
C424	56		CE04KW1V220M	ELECTRO		
C425	56		CC45FSL1H331JM	CERAMIC		
C426	56		CC45FSL1H101JM	CERAMIC		
CN1, 2			E40-4892-05	FLAT CABLE CONNECTOR		
CN3, 4			E40-4926-05	FLAT CABLE CONNECTOR		
CN5			E40-9848-05	PIN ASSY		
CN6	56		E40-3246-05	PIN ASSY		
J1			E63-0047-15	PHONO JACK		
J2			E58-0006-05	RECTANGULAR RECEPTACLE		
J3			E58-0016-05	PHONE JACK		
J4, 5			E11-0336-05	JUMPER WIRE		
W1, 25	57		E31-0001-00	JUMPER WIRE		
W7, 18	6		E31-0001-00	JUMPER WIRE		
W19	6		E31-0001-00	JUMPER WIRE		
W20-25	6		E31-0001-00	JUMPER WIRE		
W26	56		E31-0001-00	JUMPER WIRE		
W102-105	57		E31-0001-00	JUMPER WIRE		
W103-105	6		E31-0001-00	JUMPER WIRE		
W107-115	7		E31-0001-00	JUMPER WIRE		
W116	56		E31-0001-00	JUMPER WIRE		
W209, 210	67		E31-0001-00	JUMPER WIRE		
W209, 210	67		E31-0001-00	JUMPER WIRE		
W226, 227	7		E31-0001-00	JUMPER WIRE		
J6			F10-0977-14	SHIELDING PLATE		
L1			L40-1091-17	SMALL FIXED INDUCTOR(1UH)		
L2			L40-1001-17	SMALL FIXED INDUCTOR(10UH)		
L3			L19-0083-05	TRANSFORMER FOR CONVERTER		
L4, 5			L92-0054-05	FERRITE CORE		
X1			L78-0605-05	RESONATOR (8.38MHZ)		
X2			L77-2213-05	CRYSTAL RESONATOR(32.768KHZ)		
X3			L77-2002-05	CRYSTAL RESONATOR(4.332MHZ)		
CP1			R90-0479-05	MULTI-COMP		
CP2			R90-0850-05	MULTI-COMP		
R2			RS14KB3D180J	FL-PROOF RS		
R15, 16			RD14NB2E4R7J	RD		
R20			RS14KB3D3R3J	FL-PROOF RS		
R22	7		RD14BB2C104J	RD		
R35, 36	5		RD14BB2C153J	RD		
R37, 38	5		RD14BB2C272J	RD		
R50			RD14NB2E820J	RD		
R65			RS14KB3DHR22J	FL-PROOF RS		
R78, 79			RD14NB2E820J	RD		
R82	56		RD14BB2C104J	RD		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)
K : USA
P : Canada
T : Europe
X : Australia
M : Other Areas
R : Mexico
G : Germany
Q : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

C-H5/H51/H5W/H6/H61/H6W/H7

PARTS LIST

Ref. No	Add. tests	New Parts	Parts No.	Description	Desti- nation	Re- marks
Q2			2SC2785(FE)	TRANSISTOR		
Q3			2SA954(L,K)	TRANSISTOR		
Q4			2SA1175(FE)	TRANSISTOR		
Q5 .6			2SA933AS(Q,R)	TRANSISTOR		
			2SD1137(P)	TRANSISTOR		
Q5 .6			2SD2525	TRANSISTOR		
Q7			2SA1534A(R,S)	DIGITAL TRANSISTOR		
Q8			DTC113ZSA	DIGITAL TRANSISTOR		
Q8			UN4219	DIGITAL TRANSISTOR		
Q9			2SA1175(FE)	TRANSISTOR		
Q10			2SA933AS(Q,R)	TRANSISTOR		
Q11			2SC3940A(R,S)	TRANSISTOR		
Q12			2SB1168(S,T)	TRANSISTOR		
Q12			2SC1740S(Q,R)	TRANSISTOR		
Q13 .14			2SC2785(FE)	TRANSISTOR		
Q13 .14			2SA1175(FE)	TRANSISTOR		
Q15 .16			2SA933AS(Q,R)	TRANSISTOR		
Q17			2SC1845(FE)	TRANSISTOR		
Q17			2SA1175(FE)	TRANSISTOR		
Q201-203			2SA933AS(Q,R)	TRANSISTOR		
Q201-203			2SC2785(FE)	TRANSISTOR		
Q204			2SA1175(FE)	TRANSISTOR		
Q204			2SA933AS(Q,R)	TRANSISTOR		
Q205-207			2SC1740S(Q,R)	TRANSISTOR		
Q205-207			2SC2785(FE)	TRANSISTOR		
Q208			2SC1740S(Q,R)	TRANSISTOR		
Q208			2SC2785(FE)	TRANSISTOR		
Q209			2SC1740S(Q,R)	TRANSISTOR		
Q209			2SC2785(FE)	TRANSISTOR		
Q210			2SC1740S(Q,R)	TRANSISTOR		
Q210			2SC2785(FE)	TRANSISTOR		
A1			W02-2561-05	ELECTRIC CIRCUIT MODULE		

* New Parts

Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia
Y : PFI Far East, Hawaii
V : AAFES(Europe)
K : USA
T : Europe
X : Australia
P : Canada
E : Europe
M : Other Areas
R : Mexico
G : Germany
O : Russia
5 : C-H5 series
6 : C-H6 series
7 : C-H7
Δ indicates safety critical components.

SPECIFICATIONS

[FM Tuner section]

Tuning frequency range.....87.5 MHz ~ 108MHz

Sensitivity (DIN at 75 Ω)

MONO.....1.8μV / 16.2 dBf

[MW (AM) Tuner section]

Tuning frequency range 531 kHz ~ 1,602 kHz

[LW Tuner section]

Tuning frequency range 153 kHz ~ 279 kHz

[Amplifier section]

Signal to noise ratio

Line (AUX).....90 dB (1HF'A)

Input sensitivity / Impedance

Line (AUX, MD)

.....200 mV / 47 kΩ (SOURCE DIRECT ON)

Output level / Impedance

SUPER WOOFER PRE OUT

.....2.0 V / 2.2 kΩ (SOURCE DIRECT ON)

TAPE or MD REC 200 mV / 2.2 kΩ

[General]

Dimension W : 270 mm

H : 119 mm

D : 322 mm

Weight (net) 2.1 kg



1. KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.
2. Sufficient performance may not be exhibited at extremely cold locations (where water freezes).

Note:

Component and circuit are subject to modification to insure best operation under differing local conditions. This manual is based on Europe (E) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

KENWOOD CORPORATION

14-6,Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150 Japan

KENWOOD SERVICE CORPORATION

P.O BOX 22745, 2201 East Dominguez St., Long Beach, CA 90801-5745, U.S.A.